

Revolabs Classroom System—Rolls MX56c Setup Guide

This setup guide will assist you with the steps needed to properly connect the Revolabs Classroom System to a Rolls MX56c MiniMix A/V mixer. Adding the Rolls MX56c provides additional inputs for a laptop or desktop computer, additional wired microphone, or any other audio device.

Note: *It is important to carefully follow these instructions in order and completely. Otherwise, the Revolabs Classroom System may not function properly. Please read through these instructions completely before proceeding. Contact Revolabs Technical Support if you have any questions.*

Requirements for connecting systems:

1. Revolabs Classroom System
2. Rolls MX56c MiniMix A/V mixer
3. QTY 2 RCA-RCA male cable (for Rolls mixer)
4. QTY 1 3.5mm—3.5mm male cable (for computer)
5. QTY 1 3.5mm stereo—1/4" stereo male cable (for iPod or MP3 player)

Connecting the Cables

1. Set the volume of the Powered Speaker so that the white line is pointing directly upwards
2. Connect the Revolabs 2.5mm to stereo RCA cable between the AUDIO LINE of the Revolabs receiver to the STEREO LINE RCA input of the Rolls MX56c. Adjust volume levels on Input 1 of the Rolls Mixer as needed.
3. Connect a 3.5mm stereo cable between the SPEAKER or LINE OUTPUT of the computer to the STEREO LINE 3.5mm input of the Rolls MX56c. Adjust volume levels on Input 3 of the Rolls Mixer as needed.
4. Connect a 3.5mm male stereo to 1/4" mono cable between the headphone of the iPod and the MONO INPUT 1/4" input of the Rolls MX56c. Adjust volume levels on Input 4 of the Rolls mixer as needed
5. Connect two RCA male cables between the STEREO OUTPUT of the Rolls MX56c to the STEREO INPUT of the Revolabs Classroom System powered speaker

